





AUDI A5 (8T, 8F) 3.2 V6 FSi CALA
 2007 - 2012

Fuse and relay box in luggage compartment, (2010 - 07/2011)



Location 1

Left-hand drive is shown

Fuse 1

Not used

Fuse 2

Not used

Fuse 3

Not used

Fuse 4

Not used

Fuse 5

Not used

Fuse 6

Not used

Fuse 7

Not used

Fuse 8

Not used

Fuse 9

Not used



AUDI A5 (8T, 8F) 3.2 V6 FSi CALA

2007 - 2012

Fuse and relay box in luggage compartment, (2010 - 07/2011)

Fuse 10

Not used

Fuse 11

Not used

Fuse 12

Not used

Fuse 13

Not used

Fuse 14

Trailer detection control unit
Adjustable rear spoiler control unit
(10A also used)

15.0 A

Fuse 15

Trailer detection control unit
20.0 A

Fuse 16

Trailer detection control unit
20.0 A

Fuse 17

Electric parking brake

5.0 A

Fuse 18

Electronic damper control unit

15.0 A

Fuse 19

Electric parking brake control unit

30.0 A

Fuse 20

Comfort system control unit

30.0 A

Fuse 21

4WD control unit

35.0 A

Fuse 22

Comfort system control unit

30.0 A

Fuse 23

Comfort system control unit
20.0 A



AUDI **A5 (8T, 8F)** 3.2 V6 FSi CALA
2007 - 2012

Fuse and relay box in luggage compartment, (2010 - 07/2011)

Fuse 24

Fuel tank leakage control unit

5.0 A

Fuse 25

Not used

Fuse 26

Seat ventilation

15.0 A

Fuse 27

Radio

Communication control unit

TV tuner

Aerial selection control unit

Telephone

Connector T18a

40.0 A

Fuse 28

Voltage regulator(s)

40.0 A

Fuse 29

DC-AC converter with socket, 12V - 230V

30.0 A

Fuse 30

Additional heater control unit

30.0 A

Fuse 31

Electric parking brake control unit

30.0 A

Fuse 32

Heated seat switches

30.0 A

Fuse 33

Door

30.0 A

Fuse 34

Remote control receiver

5.0 A

Fuse 35

Door

15.0 A



AUDI A5 (8T, 8F) 3.2 V6 FSi CALA

2007 - 2012

Fuse and relay box in luggage compartment, (2010 - 07/2011)

Fuse 36

Not used

Fuse 37

12V socket

15.0 A

Fuse 38

12V socket

DC-AC converter with socket, 12V - 230V

15.0 A

Fuse 39

12V socket

15.0 A

Fuse 40

Cigarette lighter

15.0 A

Fuse 41

Not used

Fuse 42

Connector(s)

5.0 A

Fuse 43

Parking assistance control unit

7.5 A

Fuse 44

Not used

Fuse 45

Electric parking brake

5.0 A

Fuse 46

Lane change assist control unit 2

5.0 A

Fuse 47

Heated seat switches

5.0 A



AUDI A5 (8T, 8F) 3.2 V6 FSi CALA

2007 - 2012

Fuse and relay box in luggage compartment, (2010 - 07/2011)

Fuse 48

Electronic damper control unit
Trailer detection control unit
4WD control unit
Voltage regulator(s)
Electric parking brake control unit

5.0 A

Fuse 49

Not used

Fuse 50

Not used

Fuse 51

Radio
Digital sound package control unit
(20A also used)

30.0 A

Fuse 52

Information display control unit

7.5 A

Fuse 53

Navigation system with CD drive control unit
Radio
Communication control unit
TV tuner
Aerial selection control unit
Telephone
Connector T18a
(7.5A also used)

5.0 A

Fuse 54

Rear-view camera control unit

5.0 A

Fuse 55

Aerial selection control unit

5.0 A

Fuse 56

Not used

Fuse 57

Not used

Fuse 58

Not used



AUDI **A5 (8T, 8F)** 3.2 V6 FSi CALA
2007 - 2012

Fuse and relay box in luggage compartment, (2010 - 07/2011)

Fuse 59

Not used

Fuse 60

Not used

Fuse H

Heated rear windscreen relay

40.0 A

Relay A

Heated rear windscreen relay
or not used

Relay B

Two-way radio relay
or not used

Relay C

Heated rear windscreen relay
Or
Power socket relay

Relay D

Terminal 15 voltage supply relay
Or
Not used

Relay E

Power socket relay
or not used

Relay F

No information is available

Relay G

No information is available