





AUDI **A5 (8T, 8F)** 3.2 V6 FSi CALA  
2007 - 2012

**Fuse and relay box in luggage compartment, (08/2011 - )**

**Fuse 10**

Not used

**Fuse 11**

Not used

**Fuse 12**

Not used

**Fuse 13**

Not used

**Fuse 14**

Trailer detection control unit  
Adjustable rear spoiler control unit  
(10A also used)

15.0 A

**Fuse 15**

Trailer detection control unit  
20.0 A

**Fuse 16**

Trailer detection control unit  
20.0 A

**Fuse 17**

Electric parking brake  
5.0 A

**Fuse 18**

Electronic damper control unit  
Adaptive suspension control unit  
15.0 A

**Fuse 19**

Electric parking brake control unit  
30.0 A

**Fuse 20**

Comfort system control unit  
30.0 A

**Fuse 21**

4WD control unit  
35.0 A

**Fuse 22**

Comfort system control unit  
30.0 A



AUDI **A5 (8T, 8F)** 3.2 V6 FSi CALA  
2007 - 2012

**Fuse and relay box in luggage compartment, (08/2011 - )**

**Fuse 23**

Comfort system control unit  
20.0 A

**Fuse 24**

Fuel tank leakage control unit  
GPS system  
Secondary air pressure sensor  
5.0 A

**Fuse 25**

Not used

**Fuse 26**

Power socket relay  
20.0 A

**Fuse 27**

Voltage regulator(s)  
40.0 A

**Fuse 28**

Voltage regulator(s)  
Radio  
Digital sound package control unit  
30.0 A

**Fuse 29**

DC-AC converter with socket, 12V - 230V  
25.0 A

**Fuse 30**

Additional heater control unit  
30.0 A

**Fuse 31**

Electric parking brake control unit  
30.0 A

**Fuse 32**

Heated seat switches  
30.0 A

**Fuse 33**

Door  
30.0 A

**Fuse 34**

Remote control receiver  
5.0 A



AUDI **A5 (8T, 8F)** 3.2 V6 FSi CALA  
2007 - 2012

**Fuse and relay box in luggage compartment, (08/2011 - )**

**Fuse 35**

Door

30.0 A

**Fuse 36**

Communication control unit

Aerial selection control unit

Telephone

5.0 A

**Fuse 37**

Not used

**Fuse 38**

Not used

**Fuse 39**

Not used

**Fuse 40**

Not used

**Fuse 41**

Not used

**Fuse 42**

Not used

**Fuse 43**

Not used

**Fuse 44**

Not used

**Fuse 45**

Not used

**Fuse 46**

Not used

**Fuse 47**

Not used

**Fuse 48**

Not used

**Fuse 49**

Seat ventilation

15.0 A

**Fuse 50**

Automatic anti-dazzle rear-view mirror  
or not used

5.0 A



# AUDI A5 (8T, 8F) 3.2 V6 FSi CALA

2007 - 2012

## Fuse and relay box in luggage compartment, (08/2011 - )

### Fuse 51

Fuse box No. 1 in passenger compartment, fuses 13, 16  
or not used

30.0 A

### Fuse 52

Information display control unit

7.5 A

### Fuse 53

Chip card reader

Radio

TV tuner

5.0 A

### Fuse 54

Rear-view camera control unit

5.0 A

### Fuse 55

Not used

### Fuse 56

Connector(s)

5.0 A

### Fuse 57

Not used

### Fuse 58

Not used

### Fuse 59

Reductant metering system

30.0 A

### Fuse 60

Reductant metering system

10.0 A

### Fuse H

Heated rear windscreen relay

40.0 A

### Relay A

Heated rear windscreen relay

or not used

### Relay B

Reductant metering system relay



AUDI **A5 (8T, 8F)** 3.2 V6 FSi CALA  
2007 - 2012

**Fuse and relay box in luggage compartment, (08/2011 - )**

**Relay C**

Power socket relay  
or not used

**Relay D**

Heated rear windscreen relay  
Or  
Not used

**Relay E**

Power socket relay  
or not used

**Relay F**

No information is available

**Relay G**

No information is available